

Assembly of Pfranc Pplug



- Part names: Cylinder, Intermediate section, Cap, Pins, Screw and Plastic plug
- Insert Pins in Cylinder with gold plated contacts facing down
- Note: position of slot in Cylinder facing in your direction
- Use a drop of plastic glue when available
- Install Intermediate section as shown, cable connection to the right hand side
- Solder wires to Pins using low power solder iron
 - = 5 and Mass
 - T = 2
 - R = 3
 - + = power. Volts depending on type of gps
- Use a drop of plastic glue when available
- Install Cap over intermediate section
- Secure Cap using Screw
- Note: when 6 Volts is supplied (as required for GPS12 a.o.) the Plastic plug shall not be installed. Otherwise: install Plastic plug in centre hole of Cylinder when + is directly connected to power source. Plastic plug is a protection to prevent that 12 Volt cables are plugged into a 6 Volt gps receiver